

Scope of delivery

3 Product description

3.1 Configuration

The scope of delivery encompasses:

- VEGASWING 63 point level switch
- Documentation
 - this operating instructions manual
 - Safety Manual "Functional safety (SIL)" (optional)
 - Supplementary instructions manual "Plug connector for level sensors" (optional)
 - Ex-specific "Safety instructions" (with Ex versions)
 - if necessary, further certificates

Constituent parts

- The VEGASWING 63 consists of the components:
- Housing cover
- Housing with electronics
- Process fitting with tuning fork




Fig. 1: VEGASWING 63 with plastic housing

- 1 Housing cover
- 2 Housing with electronics
- 3 Process fitting

Type label

The type label contains the most important data for identification and use of the instrument:

- Article number
- Serial number
- Technical data
- Article numbers, documentation
- SIL identification (with SIL rating ex works)

With the serial number, you can access the delivery data of the instrument via <u>www.vega.com</u>, "VEGA Tools" and "serial number search".